





Vison KUMO Pop-Up Display System

SET UP INSTRUCTIONS




1. Your display comes in either one oval case or two semi-oval cases. Unpack the frame and channel bars.
2. Expand the frame, make sure the frame is right side up-the row of large yellow buttons is at the top of the frame and facing you. The row of large blue buttons is at the bottom of the frame.




3. The frame is self-locking; to unlock, simply pull open a blue & red large button. The frame will collapse smoothly.
4. The elasticized channel bar is set by expanding top & bottom sections so that the channel bar is vertically straight.


Vison KUMO Pop-Up Display System



5. Turn the channel bar toward you with the magnets facing you & the top with two small pins pointing up. Start by dropping the open vee of the bottom onto the lowest blue pin closest to the floor. Slide the middle section up & insert the blue pin into the hole, then drop the middle section down, locking the pin. Repeat with the next pin and finally the top is slid onto the yellow pin. Repeat with the rest of the channel bars, including the last two on the back outside.



6. Unpack panels. Attach the end panels (these are smaller panels in the curve system) by hooking up the panels to the end screw on the channel bar at the corner of the frame and wrapping the panel around to hook on to the other corner screw on the channel bar located at the back corner of the frame. Align magnet.



7. Attach the front panels to the front side of the frame by simply hooking up to the screw heads on the channel bars and aligning the magnet.

8. When repacking the panels make sure the fabric/graphic mural side is on the outside of the roll. Roll panels individually. DO NOT roll two or more panels together.

9. When removing the channel bar from the frame, simply lift it up near each of the snap-on hubs. Then gently push the bar upwards.

