




## Banner Stands

### **Banner Stand Setup & Repacking**

---



1. Remove BannerBug base from the padded case and place it on floor.
2. Remove the three support bars (connected by bunji chords) from the case and connect together to form one long pole.
3. One end of the pole is tapered to fit into a recession inside of the base of the stand. A white label indicates that this end is inserted into the base.
4. Insert the plastic clip in the rail holding the top of the banner into the non-tapered end of the pole (the end without a label).
5. Lift the banner straight up while holding down the base with your foot.
6. Insert the tapered end of the pole into the base and move it around until it slips into the recession in the base.
7. When repacking the BannerBug, stand the base on end. **Gently slide the carrying case over the base.** Make sure that the side with the rail is opposite the side which has the compartment for the poles. Finally, slide the poles into the carrying case.