



Instruction Sheet

DuraFly Assembly Instructions


Parts List



Cross Base




Poles




Ground Auger



Water Bag



Banner



Bungee Cord


* Depending on the option you choose, you will have either a Ground Auger or a Cross Base and Water Bag.

Installing the Ground Auger

This will take a few minutes and may be labour intensive, depending on the condition of the soil. Decide where you'd like to have the DuraFly, insert the included metal pole through the horizontal hole in the Ground Auger and begin turning the auger into the soil until it is firmly in place.

Setting Up the DuraFly

1. Begin by unpacking your DuraFly kit and ensure you have the required parts. Your poles ship inside of each other. The pole has one plug on each end. Remove the plug from the large end only. Slide out the other two poles. Remove the opposite plug (smaller end) when ready to assemble. It is important that you remove each piece, lay them on a flat surface, and then put each piece together. Do not telescope the poles as this causes them to break. There is only one correct way for the poles to attach together.
2. Connect poles as they are labelled ('A' to 'A' and 'B' to 'B').
3. Unfold your banner and lay it down on a flat surface, feed pole through sleeve. Note, the top of the pole has a rubber tip on it which can make this step a bit difficult, but don't worry, it's just the rubber tip catching on the fabric - ensure the pole reaches the end of the sleeve.
4. Depending on your chosen application, the bungee hooks on to the grommet and either the Auger or the Cross Base. There is a plastic and metal loop at the base of the stand. This is where the other end of the bungee is to be hooked. If you choose to display the DuraFly indoors, you should use the Cross Base. If you choose to display the DuraFly outdoors on a hard surface, use the Cross Base with the Water Bag. Fill the Water Bag with tap water, close the lid and then place the filled bag over the legs of the Cross Base before attaching the Bungee. If you intend to have the DuraFly outside for a more long-term period of time, use the Ground Auger. If your banner is for a parade setting you may carry it without any floor mount. In this case, you would hook the end of the bungee into the bottom of the pole.



Attention:

When disassembling poles, detach each pole piece. The poles fit back inside each other for convenient transportation. Insert the smaller plug on the largest pole first. Next, insert the medium-sized pole into the large pole, narrow-end first. Then insert the smallest pole into the medium pole, narrow-end first. Finally, insert the large plug to keep the other poles inside.